



CAUTION

Turn off the main power at the circuit breaker before installing the fixture in order to prevent possible shock. If you are unfamiliar with proper electrical wiring connections, obtain the services of a qualified electrician.

GENERAL

Read all instructions carefully for safe operation and installation. All electrical connections must be in accordance with local and national electrical code (N.E.C.) standards. Remove the fixture and mounting package from box. Make sure no parts are missing by referencing these Installation Instructions. Please contact Blackjack Lighting at 847-941-0588 if any parts are missing or damaged. This product is suitable for DAMP locations.

PREPARATION

1. Remove fixture/housing and diffuser(11, 13) from box.
2. Remove backplate(10A or 10B) from box.
3. Remove driver assembly(with mounting plate)(15, 16 and/or 17) from box.
4. Pull the supply wires(2 & 4) and the house ground wire(6) out of outlet box(1).

MOUNTING

5. **For Shallow Backplate(10A):** Take driver assembly(15, 17 or 16, 17) and push the white fixture wire(3) and the black fixture wire(5) through the round hole next to the rectangular opening in the backplate(10A or 10B) [See Illustration 1]

5A. Attach driver mount plate(17) to back panel(10A) with mounting screws(18).

- 5B. **Optional:** For the 120-277V driver assembly(16, 17) also push the driver pink and purple dimming wires(20, 21) (for 0-10V) through the round hole next to the rectangular opening in the backplate(10A or 10B) and connect to the house purple and pink dimming wires(20A, 21A) with wire connectors. [See Illustration 1]

6. **For Deep Backplate(10B):** Remove white driver mounting plate(17) from driver(15 or 16) by removing driver plate mounting screw(18). Attach driver(15 or 16) directly to rear of deep backplate(10B) by inserting screws and nuts(18).

- 6A. Arrange the driver and dimming wires through large center hole in backplate(10B). [See Illustration 2]

ELECTRICAL CONNECTIONS

7. Using the wire connectors(8), connect the white supply wire(2) to the white fixture wire(3); connect the black supply wire(4) to the black fixture wire(5) and connect the fixture ground wire(7) to the house ground(if applicable).

8. If required, connect 0-10V pink and purple dimming wires(20, 21) to similar color dimming wires found in outlet box(1).

9. Attach the backplate(10A or 10B) to outlet box(1) by inserting mounting screws(9) through the slots in the back panel(10) and then tightly secure the mounting screws(9) into the outlet box(1). [See Illustration 3]

ADJUST CCT SWITCH

10. On the back of housing(11) is a slide switch(19) that shows four different CCT options for this fixture. Position the switch next to the desired color temperature. [See Illustration 4]




ILLUSTRATION 1




ILLUSTRATION 2




ILLUSTRATION 3

FINAL ASSEMBLY

11. Secure the fixture housing(11) to the lens diffuser(13). Align the screws coming from the side of the lens diffuser(13) with the holes in the fixture housing(11). Then insert the screws and hand tighten the two knurled nuts(23).

12. Connect white microconnector(14A) coming from driver assembly to microconnector(14B) coming from fixture.

13. Position assembled fixture housing(11) to attach to backplate(10A or 10B) and fasten the two side screws(12) into the side of backplate(10A or 10B).

[See Illustrations 5 & 6]




ILLUSTRATION 4

DIMMING

14. Dimming type: TRIAC or ELV dimming with 120V standard driver(15) or TRIAC, ELV, and 0-10V dimming with 120-277V upgraded driver(16).




ILLUSTRATION 5
Shallow Backplate




ILLUSTRATION 6
Deep Backplate

1. OUTLET BOX (BY OTHERS)	11. FIXTURE HOUSING	19. CCT SWITCH
2. WHITE SUPPLY WIRE	12. SIDE SCREWS	20. PINK 0-10V DRIVER DIMMING WIRE
3. WHITE FIXTURE WIRE	13. ACRYLIC LENS/DIFFUSER	20A. PINK 0-10V DIMMING WIRE (OPTIONAL)
4. BLACK SUPPLY WIRE	14A. WHITE MICROCONNECTOR FROM DRIVER	21. PURPLE 0-10V DRIVER DIMMING WIRE
5. BLACK FIXTURE WIRE	14B. WHITE MICROCONNECTOR FROM FIXTURE	21A. PURPLE 0-10V DIMMING WIRE (OPTIONAL)
6. DIFFUSER MOUNTING SCREWS (2)	15. 120VAC DRIVER	22. LOW VOLTAGE WIRES TO LED
7. FIXTURE GROUND WIRE	16. 120-277VAC DRIVER	23. KNULED NUTS (2)
8. WIRE CONNECTORS	17. DRIVER MOUNTING PLATE	
9. BACK PLATE MOUNTING SCREWS	18. DRIVER / DRIVER PLATE MOUNTING SCREWS (2) AND NUTS (4)	
10A. SHALLOW BACKPLATE		
10B. DEEP BACKPLATE		

HARDWARE



Wire Connector (#8)
(3 included)



Back Plate Mounting Screw (#9)
(2 included)



Side Screw (#12)
(2 included)



Driver Plate Mounting Screw and Nuts (#18)
(2 screws & 4 nuts included)